

VISION TECHNICAL MANUAL

Default codes (change default codes)

Setup (Master)	5-0-5-0-5-0-5-0
Service	not installed
Manager	1-2-3-4-5-6
Users (1-9)	not installed

Open the lock

- Enter the code and open within 4 seconds.
- If time delay is set wait for counting: an acoustic signal indicates open window.
- Enter the code and open within 4 seconds.

Open the lock with time delay override

- Enter override user (9) code.
- Enter second code and open within 4 seconds.

If lock is already counting time delay enter override user (9) code to immediately open.

Change code (door open)

- Press and hold 0 until double beep: enter old code.
- Enter and confirm new code.

Install a user

- Press and hold 1 until double beep: enter Manager code.
- Enter user ID (1-9).
- Enter and confirm new user code.

To install Manager enter the function with Service code.

Users management

- Press and hold 2 until double beep: enter Manager code.
- Press P to scroll users list and check their status.
- Press 1 to install a user: enter and confirm user code.
- Press 2 to disable/enable a user.
- Press 3 to delete a user.
- Press OK to confirm and exit.

Delete a user

- Press and hold 3 until double beep: enter Manager code.
- Enter user ID (1-9).

To delete Manager enter the function with Service code.

Test function


- Press and hold 5 until double beep.
- Enter the sequence: 1-2-3-4-5-6-7-8-9-0.
- Double beep: key properly working. Long beep: key malfunction.

If lock and keypad don't communicate display shows the message: NO ANSWER.



CODE
o o o o o o

OPEN
LOCK



CHANGE
o o o o o o

INSTALL
o o o o o o

+ ID= 1

⌚ ID= 2

✗ ID = 3

DELETE
o o o o o o

TEST

Change Setup code (Master)

- Press and hold 8 until double beep, enter Setup code and select function 0.
- Enter and confirm new Setup code.

FUNCTION
0 1 3 5 6 7 9

Install Service

- Press and hold 8 until double beep, enter Setup code and select function 1.
- Press OK to confirm the operation.
- Enter and confirm new Service code.

FUNCTION
0 1 3 5 6 7 9

Delete Service

- Press and hold 8 until double beep, enter Setup code and select function 3.
- Press OK to confirm the operation.

FUNCTION
0 1 3 5 6 7 9

Reset lock

- Press and hold 8 until double beep, enter Setup code and select function 5.
- Display shows the message RESET.
- Press OK to confirm the operation.
- Enter a valid code.
- Lock is in pre-setup mode.

FUNCTION
0 1 3 5 6 7 9

RESET

Pre-setup mode

- To open press 1.
- Setup code (Master) 5-5-5-5-5-5-5.

Lock setup

- Press and hold 8 until double beep. Enter the Setup code 5-5-5-5-5-5-5.
- Display shows the following options (press P to scroll):
 - CHANGE: change Setup code to exit pre-setup mode.
 - SETUP: check (OK) or change (P) lock configuration (**bold** = default settings)
 - **DELAY DOWN** - DELAY UP: time delay counting up or down.
 - **DUAL NO** - DUAL YES: dual mode active - dual mode not active.
 - **DIGITS 6** - DIGITS 7 - DIGITS 8: opening codes length.

Time delay

- Press and hold 9 until double beep and enter Manager code (or Service code) or access Setup menu and press 9.
- Display shows current time delay values: press OK to confirm or enter new values (00-99min) and press OK.
- Display shows current open window values: press OK to confirm or enter new values (01-19min) and press OK.

Time delay can be increased at any moment, decreased only during open window.

DELAY
0 0 0 0 0 0

DELAY
05min?

WINDOW
02min?

Change language

- Press and hold OK until double beep: display shows the current language.
- Press OK until the desired language will be selected.

ENGLISH
ITALIAN?

Check firmware version

- Press and hold OK until double beep: display shows the current language.
- Press P: display shows serial number and firmware version.

42C1AH90
VER. 01.01